

## EM Series DVR Menu Tree

(See also Page 14 in the users manual)

### Setup Menu

1. Live
  1. OSD
  2. Sequence
  3. Seq-Dwell time
  4. Event Beep
  5. OSD contrast
  6. Channel
    1. Display
    2. Seq. list
    3. Brightness
    4. Contrast
    5. Hue
    6. Saturation
2. Record
  1. Resolution
  2. Channel
    1. Frame rate
    2. Quality
    3. Recording
    4. Motion Zone
    5. Motion sensitivity
    6. Sensor type
    7. Pre-record
    8. Post event record
    9. Alarm
    10. Alarm duration
    11. Audio
  3. Schedule
3. System
  1. DVR ID
  2. Description
  3. Load factory default
  4. Admin Password
  5. Network password
  6. Date format
  7. Set date & time
  8. PTZ control
    1. Camera Speed
    2. Camera number
    3. Camera type (protocol)
    4. Camera ID
  9. Language
  10. Remote controller ID
4. Network
  1. Port
  2. Client access
  3. Bandwidth saving
  4. Network Type – DHCP / ADSL / LAN
    - ADSL – IP, Password
    - LAN – IP address, Gateway, Subnet Mask, DNS server IP
  5. DDNS
    1. Server name
5. Storage
  1. Overwrite
  2. Format
6. Save
  - Confirm / Cancel